

Parts


AUTHORITY

125 Redwood Circle, Fayetteville, Georgia 30214 770.719.9492
FAA Parts Manufacturing Authority PQ4173CE

“Your Source for Aerostar PMA Parts”

AEROSTAR PARTS MANUAL

FABRIC USAGE CHARTS





Fabric Usage Chart
RX6


Legend

▲.....circumferential band

○.....equator









**Fabric Usage Chart
RX9**

Legend

▲.....circumferential band

○.....equator






**Fabric Usage Chart
S50A**

Legend

▲.....circumferential band


○.....equator





Fabric Usage Chart S51A

Legend

- ▲.....circumferential band
-equator
-cut locations for fabric 60" or less.










**Fabric Usage Chart
S53H**


Legend

▲.....circumferential band
○.....equator










Fabric Usage Chart
S57H

Legend


- ▲circumferential band
○equator



**Fabric Usage Chart
S60A**

Legend

▲.....circumferential band
 ○.....equator
 ●.....optional S.P. band



**Fabric Usage Chart
S60H**

Legend

▲.....circumferential band

○.....equator

